



TOSHIBA

VOICE MAIL USER GUIDE

To Record Messages

- 1, Press Speaker
- 2, Enter 250 or 500 to call Voicemail

Please enter your security code finish by pressing #

- 3, Enter *#

That security code is invalid, enter your User ID finish by pressing #

- 4, Enter your message number to be recorded followed by #
 - 400 First Day Message
 - 401 Second Day Message
 - 402 Holiday Message
 - 403 Night Message

Enter your security code, finish by pressing #

- 5, Re-Enter the above number again

You have no new messages.....

- 6, Press MGMT on the buttons below the screen

To change your greeting.....

- 7, Press GRT on the buttons below the screen

To select a greeting select 1 through 7.....

- 8, Enter 1

Greeting 1 selected.....

- 9, Lift handpiece
 - Follow prompts
 - Press REVW to Listen to review current Greeting
 - Press REC to Record over the current Greeting